


ORIGINAL HEIDELBERG

10¹/₄" x 15" - 26 x 38 cm

13¹/₂" x 18¹/₂" - 34 x 46 cm

OPERATION MANUAL



HEIDELBERGER DRUCKMASCHINEN AKTIENGESELLSCHAFT

SALES AND SERVICE THROUGHOUT THE WORLD

Please keep this manual in the pressroom

PREFACE

This Manual is intended as an aid to the printer who has not become acquainted with the Heidelberg. Our press erectors train the pressmen who will operate the press. In printing establishments where labour conditions permit, two persons should be trained for every press installed.

Moreover, the printer who has already worked on our presses should also read this Manual in order to become thoroughly conversant with the operation of the

ORIGINAL HEIDELBERGS.

We have intensified our efforts to make life easier for the printers using our presses in all five Continents by simplifying the operation of the new model presses and by including many new devices.

It is thus possible to benefit more thoroughly than ever before from the many unique advantages of the

ORIGINAL HEIDELBERGS.

The Heidelbergs are genuine all-purpose presses, printing anything that can be locked in their chases from a business card to the maximum sheet, from "air mail" (onion skin) to heavy cardboard, from a simple one-colour job to the most difficult four-colour process work. This reliable and unassuming workhorse of the pressroom handles all jobs, feeding and delivering one, two or more pieces of stock simultaneously with maximum speed and quality.

Now, may we make a request and a recommendation?

- (1) Please lubricate the Original Heidelberg in exact conformity with the lubricating instructions on the press, daily, weekly, or half-yearly, as the case may be.
- (2) Please clean the press regularly, especially after the spray gun has been in use.
- (3) Please keep the blow holes in the right-hand track and on the delivery blower open and clean.

This takes only a few minutes each day. The Heidelberg will respond by giving you efficient performance for many years without repairs and without the wear and tear caused by neglect.

Take care that the movement of the inking roller carriage is disengaged **only when the press is stopped** and the platen is closed.

This edition of the Manual again finds Manual and Spare Parts Catalogue separated. The Manual is to be kept with the press, while the Spare Parts Catalogue should be filed in your office.

Here is still another suggestion. Inks for platen presses should be of short consistency or should be adjusted by the pressman. The greater the care expended upon the ink adjustment, the greater the running speed and the production speed. All leading ink manufacturers supply special inks for high-speed automatic Platens.

We hope this Manual will contribute to the continued expert maintenance of the

ORIGINAL HEIDELBERG

so that this highly efficient automatic platen can prove its superiority for the benefit of its owner.

HEIDELBERGER DRUCKMASCHINEN
AKTIENGESELLSCHAFT

CONTENTS

	Page
Index	4
Table of Most Important Adjustments for Various Stock	8
Specifications for the Original Heidelbergs	9
Drip Tray	10
Cleaning the Press	10
Air Filter on the Pump	11
Air Filter in the Suction Air Line	11
Lubricating the Press	12
Hints for the Treatment of Rubber Rollers	16
Printing of Mixed Formes (Halftones and Type Matter)	17
Printing Illustrations on Original Heidelbergs 10×15" and 13×18"	18
Printing of Solids on Original Heidelbergs	20
Repeats (Ghosting)	21
Printing of Multi-Colour Jobs	22
Driers	23
A few Hints on Running Thin Stock	23
Mechanical Makeready Systems	24
Slurs in Platen Press Printing	26
Die-Cutting on the Original Heidelbergs 10×15" and 13×18"	28
Embossing on the Original Heidelbergs 10×15" and 13×18"	29
Original Heidelberg Platen Cutter and Creaser 13×18"	32
Carbon Printing on the Original Heidelbergs 10×15" and 13×18"	34
Numbering	36
Switch for Starting Motor	38
Starting and Stopping the Press	38
Speed Regulation	39
Replacing the V-belt	42
Locking the Forme	43
Device for Pre-Registering Formes	45
Packing	46
Clamps for the Packing	47
Fastening the Packing on the Gripper Side	48
Slot Gauge for Packing Thickness	49
Makeready	50
Adjusting Impressional Strength	51
Adjustments when Printing with Bottom Guides	52
Changing the Bottom Guides	54
Adjusting Bottom Guides	56
Adjusting the Slide Spring	58
Micro-Adjustment of Bottom Guides	59
Adjusting Side Guide	60
Adjusting the Paper Tables	60
Obtaining Position	62
Loading Stock	63
Loading Narrow Stock for Register Work	63
Sheet Steadier	64
Sheet Slow-Down Finger	64
Sucker Bar Slides	65
Vacuum Release on Sucker Bar	66
Rubber Discs for Cardboard	66
Lateral Adjustment of Sucker Bar	67
Changing the Angle of the Front Feed Guide	67
Feed Air Blast	68
Obtaining Good Sheet Separation on the Feed Table	68
Adjusting the Position of the Feed Blower	70
Setting Tilt of Sucker Bar	70
Feed Lift	71
Button for Tripping Suction	72
Automatic Throw-Off	72
Running Very Thin Stock	73
Extra Accessory for Printing Very Thin Stock (T 801/802)	74
Standard Two-Up Feed	75